



We recommend a battery-backed Uninterruptable Power Supply [UPS]

telephone system operation.

so that no other devices trip the circuit breaker and cause interruption of your